Andrews & Loiversity



Where is a Fire Rate d Door Located?

Fire rated doors are typically used in three major areas.

- 1. Stairwells To protect the area used by building occupants to evacuate the building by preventing smoke/fla mes from entering the stairwell (Figure 1)
- 2. Fire Stops Located in long hallway type areas to prevent smoke/flames from spreading throughout an entire fl oor (Figure 2).